



No.	Part No.	Husqvarna Part No.	Description	Qty.
1	B01090602563	522378301	BOLT	6
2	14000F08F000	#N/A	COVER, CRANKCASE	1
3	26133F02F000	#N/A	WASHER, SEAL	2
4	14216F02F020	#N/A	DIPSTICK	1
5	35105F02F000	#N/A	SEAL SPACER	1
6	26201F02F000	#N/A	GASKET, CRANKCASE	1
7	26208F02F000	#N/A	GUIDE DOWEL	4
8	B01090601263	#N/A	BOLT	2
9	B01090601463	#N/A	BOLT	3
10	B070100060B6	#N/A	PLAIN WASHER	1
11	B070000060B6	#N/A	SPRING WASHER	1
12	B12016620350	#N/A	BEARING	1
13	B12016620250	522388701	BEARING	1
14	26204L01F000	#N/A	SPACER, DRAIN PLUG	2
15	26202F02F000	#N/A	DRAIN PLUG	2
16	26001F03F000	#N/A	CRANKCASE ASS'Y	1

No.	Part No.	Husqvarna Part No.	Description	Qty.
17	B01090602063	#N/A	BOLT	2
18	17451F08F000	#N/A	PLATE 1 DRIVERION	1
19	17452F08F000	#N/A	PLATE 2 DRIVERION	1
20	17550F02F000	#N/A	CLIPBOARD	1
21	17627K07F000	522241701	PIN	1
22	26146L01F000	522251801	SNAP SPRING	1
23	17202F08F000	#N/A	GROUNDED FIRE ASS'Y	1
24	30503F03F000	#N/A	GASKET, CYLINDER HEAD	1
25	30504F02F000	#N/A	BOLT, CYLINDER HEAD	4
26	30730F08F000	#N/A	CYLINDER HEAD	1
27	30715F02F000	#N/A	GASKET INLET PIPE	2
28	30548F02F000	#N/A	SPACER, HEAT INSULATING	1
29	30520F02F000	#N/A	BOLT, INTAKE PIPE	2
30	B04070600053	522383601	NUT	2
31	30702F02F000	#N/A	GASKET, CYLINDER HEAD COVER	1
32	30700F02F000	#N/A	CYLINDER HEAD COVER	1
33	B01090601263	#N/A	BOLT	4
34	30532F02F000	#N/A	SPACER, EXHAUST PIPE	1
35	30521K07F000	522262701	BOLT, EXHAUST PIPE	2
36	B04070800053	#N/A	NUT	2
37	B07000000800	522386901	SPRING WASHER	2
38	30506F02F000	#N/A	SPARK PLUG	1
39	26400K07F000	#N/A	COLLOID PIPE	1
40	30230F02F000	#N/A	ROCKER BRACKET ASS'Y	1
41	30235F02F000	#N/A	ADJUSTING NUT, VALVE CLEARANCE	1
42	30232F02F000	#N/A	ROCKER SHAFT	2
43	30233F02F000	#N/A	LEFT ARM	1
44	30234F02F000	#N/A	RIGHT ARM	1
45	30231F02F000	#N/A	ROCKER BRACKET	1
46	B08000000100	#N/A	BLOCK CIRCLE	2
47	30303F02F000	#N/A	ADJUSTING STUD, VALVE CLEARANCE	2
48	30106F02F000	#N/A	UPPER RETAINER, DOOR SPRING	2
49	30101F02F000	#N/A	SPRING, VALVE	2
50	30201F02F000	#N/A	VALVE, EXHAUST	1
51	30105F02F000	#N/A	RETAINER INTAKE DOOR SPRING	1
52	30237F02F000	#N/A	ROD, CONNECTING	2
53	30103F02F000	#N/A	VALVE, INTAKE	1
54	30312F02F000	#N/A	STUD, CONNECTING	2
55	30400F02F000	#N/A	CAMSHAFT	1
56	B01090601663	#N/A	BOLT	4

No.	Part No.	Husqvarna Part No.	Description	Qty.
57	15230F02F000	#N/A	NUT, CLAMP	1
58	15116F02F000	#N/A	KEY	1
59	15200F08F000	#N/A	CRANKSHAFT ASS'Y	1
60	15237F02F000	#N/A	SMALL GEAR, CRANKSHAFT	1
61	15201F02F000	#N/A	CRANKSHAFT	1
62	15207F02F000	#N/A	BIG GEAR, CRANKSHAFT	1
63	15106F02F000	#N/A	CIRCLIP, PISTON PIN	2
64	15100F02F000	#N/A	PISTON	1
65	15400F03F000	#N/A	PISTON RING ASS'Y	1
66	15103F03F000	#N/A	RING, FIRST	1
67	15104F02F000	#N/A	RING, SECOND	1
68	15300F03F000	#N/A	OIL RING ASS'Y	1
69	15105F02F000	#N/A	PISTON PIN	1
70	15130F03F000	#N/A	CONNCTING ROD ASS'Y	1
71	15133F02F000	#N/A	CONNECTING ROD BOLT	2
72	15132F02F000	#N/A	CONNECTING ROD COVER	1
73	15131F02F000	#N/A	CONNECTING ROD BODY	1
74	17581F02F000	#N/A	ARM	1
75	17594F02F000	#N/A	ROD TENSION	1
76	17593F02F000	#N/A	SPRING 2, TENSION	1
77	B04070600063	#N/A	NUT	2
78	17586K07F000	522239901	SPACER 3	1
79	17583Q01F000	522239201	CIRCLIP	1
80	17582F02F000	#N/A	FORK	1
81	B08030000600	#N/A	BLOCK CIRCLE	1
82	17164Q01F000	#N/A	SPACER 2	1
83	17580F02F000	#N/A	CENTRIFUGAL ASS'Y	1
84	17587F02F000	#N/A	ADJUSTMENT, CENTRIFUGAL	1
85	17588F04F000	#N/A	CENTRIFUGAL BLOCK	2
86	17591Q01F000	522241001	PIN	2
87	17582Q01F000	522239001	COVER, PUSH ROD	1
88	17592F02F000	#N/A	SPRING 1, TENSION	1
89	34301F02F000	#N/A	FLYWHEEL	1
90	34351F02F000	#N/A	IGNITION COIL	1
91	37000F08F000	#N/A	AIR CLEANER ASS'Y	1
92	37101F08F000	#N/A	AIR CLEANER COVER	1
93	37102F02F000	#N/A	AIR CLEANER ELEMENT	1
94	37121F02F000	#N/A	BELOW SHELL	1
95	37122F02F000	#N/A	SUSTAIN BOARD	1
96	37112F02F000	#N/A	BOLT	2

No.	Part No.	Husqvarna Part No.	Description	Qty.
99	32501F08F000	#N/A	FUEL HOSE	1
100	32623H03F000	522266601	CIRCLIP	2
101	36000F08F000	#N/A	MUFFLER ASS'Y	1
102	B1090601263	#N/A	BOLT	4
103	B070100060B6	#N/A	PLAIN WASHER	1
104	B070000060B6	#N/A	SPRING WASHER	1
105	36001F08F000	#N/A	MUFFLER BRACKET	1
106	32145F02F000	#N/A	FILTER NET	1
107	29110F02F000	#N/A	FUEL TANK	1
108	32137K07F000	#N/A	FUEL TANK CAP	1
109	17180F08F020	#N/A	STARTER ASS'Y	1
110	181051C03000	#N/A	HANDLE	1
111	17160F08F000	#N/A	PULL ROPE	1
112	20801F08F000	#N/A	CLOCKWORK SPRING	1
113	17155F02F000	#N/A	ROTARY CABLE	1
114	17161F02F000	#N/A	SPRING, RETURN	2
115	17180F02F000	#N/A	SCREW	1
116	17157F02F000	#N/A	GUIDE PAN	1
117	17158F02F000	#N/A	CLAMP	2
118	17170F02F020	#N/A	STARTER COVER ASS'Y	1
119	B01090601064	522377901	BOLT	3
120	B01090601263	#N/A	BOLT	4
121	17445F08F000	#N/A	STARTER CANISTER	1
122	20401F02F000	#N/A	FAN WHEEL	1
123	17179F08F000	#N/A	ENGINE SIDE COVER	1
124	B01090601064	522377901	BOLT	2
125	17181F02F020	#N/A	THROTTLE LEVER	1
126	B02090401354	#N/A	SCREW	2
127	17201F02F000	#N/A	THROTTLE PANEL	1