



www.outdoorliving.com

No.	Part No.	Husqvarna Part No.	Description	Qty.
1	9228A10606	#N/A	SHAFT ASSEMBLY 25mm	1
2	9228A10604	522343901	FLEXIBLE SHAFT	1
3	9038A10605	#N/A	GEAR HOUSING - UPPER	1
4	9SXABM0530	#N/A	SCREW	2
5	9SDABM0510	#N/A	SCREW	1
6	6SQAB0414	#N/A	SCREW	16
7	6MB60701	#N/A	BEARING	2
8	9127A10602	#N/A	SHAFT	1
9	9073A10601	#N/A	GEAR	2
10	9014A10601	#N/A	WASHER	1
11	9073A10602	#N/A	GEAR	2
12	6WFB06	522315201	WASHER	1
13	6NGB06	522302801	NUT	1
14	9127A10601	#N/A	INPUT SHAFT	1
15	6CD10	#N/A	C RING	4
16	9038A10606	#N/A	GEAR HOUSING - LOWER	1
17	9SXAB0520	#N/A	SCREW	3

No.	Part No.	Husqvarna Part No.	Description	Qty.
18	6DB600001	522300401	BEARING	4
19	9014A10603	#N/A	GASKET	1
20	9068A10604	#N/A	LOCKING HANDLE	1
21	6WFB0515	522315101	WASHER	1
22	9068A10603	#N/A	HANDLE	1
23	9038A10607	#N/A	HOUSING (L), BLADE	1
24	9040A10601	522330001	COUNTERWEIGHT	2
25	9038A10608	#N/A	HOUSING (R), BLADE	1
26	9017A10602	#N/A	COVER	1
27	6CC08	522299201	C RING	1
28	9228A10602	522343801	BLADE ASS'Y	1
29	9102A10602	#N/A	PLATE	1
30	9127A10603	#N/A	OUTPUT SHAFT	1
31	9157A10601	#N/A	FELT	1
32	9157A10602	#N/A	FELT	1
33	9012A10601	#N/A	GASKET	1
34	6272840003	#N/A	SCREW	3
35	6NGB05	522302701	NUT	2
36	9101A10601	#N/A	BLADE COVER	1
37	9014A10604	#N/A	WASHER	1
38	9050A10601	522330301	GASKET	1
39	9105330301	522160701	DUST CAP	1
40	9050A10602	#N/A	WASHER	1
41	9050A10603	#N/A	GASKET	2
42	9023336201	522131101	ADJUSTMENT HANGER	1