



Parklands


POWER PRODUCTS

PED - 51Y


Edger King KB51Y IPL

ENGINE ASSY

ASSEMBLY		QJ PART NO.	QJ CODE	NAME	QTY/ASSY
Engine Top-Level Ass'y	1	GB/T5783	B01270806666	Bolt, M8X66	2
Engine Top-Level Ass'y	2	KB21Y.07-05	454009960950	Cover, Engine Pulley	1
Engine Top-Level Ass'y	3	KB21Y.07-06	454000280302	Spacer, Sleeve	2
Engine Top-Level Ass'y	4	GB/T5783	B01271802066	Bolt, M8*1-20	1
Engine Top-Level Ass'y	5	GB/T93	B07000008002	Springwasher 8	1
Engine Top-Level Ass'y	6	KB21Y.07-02	454000160902	Flatwasher	1
Engine Top-Level Ass'y	7	KB21Y.07-01	454009960800	Pulley, Half "V"	2
Engine Top-Level Ass'y	8	KB51Y.01.01	468010010100	Engine Sub-level Assembly w/ Labels	1
Engine Top-Level Ass'y	8.1	For Reference Only	For Reference Only	Engine Sub-Level Assembly	1
Engine Top-Level Ass'y	8.2	KB21Y-B.09-04	454009951900	Oil Hang Tag - Fuel Tank	1
Engine Top-Level Ass'y	8.3	KB21Y-B.09-17	454009952900	Oil Hang Tag - Oil Dipstick	1




Frame Ass'y					
Frame Ass'y	1	KB51Y.08.01A	468010010200	Frame Sub-Assembly	1
Frame Ass'y	1.1	For Reference Only	For Reference Only	Frame	1
Frame Ass'y	1.2	ZJ151FEH-B.00-05	17194K14F001	Label, Oil Fill	1
Frame Ass'y	1.3	ZJ168FJH.12-01	188039950000	Label, Rear Wheel Adjust	1
Frame Ass'y	2	GB/T5789	B01310806566	Bolt, M8X65	2
Frame Ass'y	3	GB/T5789	B01310807066	Bolt, M8X70	2
Frame Ass'y	4	KB21Y.08-01	454009961250	Strap	1
Frame Ass'y	5	GB/T6187.1	BC4410800066	Nut, M8	4




REAR WHEEL ASSY

Fixed Rear Wheel Ass'y	1	GB/T6187 1	B04411000066	Nut, M10	1
Fixed Rear Wheel Ass'y	2	KB21Y.04-05	454000160502	Flatwasher	1
Fixed Rear Wheel Ass'y	3	KB21Y.04-04	454000280202	Spacer, Sleeve	1
Fixed Rear Wheel Ass'y	4	KB31Y.02.01	454020011300	Tire & Rim	1
Fixed Rear Wheel Ass'y	5	KB21Y.04-03	454009880703	Bolt	1




ADJ REAR WHEEL ASSY

Adj. Rear Wheel Ass'y	1	KB21Y.04-02	454000120102	Cotter Pin	1
Adj. Rear Wheel Ass'y	2	KB21Y.04-01	454000160402	Flatwasher	2
Adj. Rear Wheel Ass'y	3	KB31Y.02.01	454020011300	Tire & Rim	1
Adj. Rear Wheel Ass'y	4	KB21Y.03-02	454002250102	Rod, Wheel Support	1
Adj. Rear Wheel Ass'y	5	GB/T14	B01050805066	Bolt, M8X50	1
Adj. Rear Wheel Ass'y	6	KB21Y.03-01	454002340002	Clvis	1
Adj. Rear Wheel Ass'y	7	GB/T5789	B01310801666	Bolt, M8X16	2
Adj. Rear Wheel Ass'y	8	KB21Y.03-03	454000370002	Bracket, Curb Flap Mnt	1
Adj. Rear Wheel Ass'y	9	GB/T6187.1	B04410800066	Nut, M8	2
Adj. Rear Wheel Ass'y	10	KB21Y.07-07	454000280402	Spacer, Sleeve	1
Adj. Rear Wheel Ass'y	11	KB21Y.02-02	454000160302	Flatwasher	1
Adj. Rear Wheel Ass'y	12	KB21Y.03.01	454000011480	Knob, Wing M8	1
Adj. Rear Wheel Ass'y	13	GB/T6182	B04340800066	Nut, M8	1




FRONT WHEEL ASSY


Front Wheel Ass'y	1	GB/T6187.1	B04421000066	Nut, M10X1.25	1
Front Wheel Ass'y	2	KB21Y.01-09	454000160206	Flatwasher	1
Front Wheel Ass'y	3	KB21Y-B.01.03	454000015701	Lever, Height Adjust Assembly.	1
Front Wheel Ass'y	3.1	KB21Y.01-08	454009980181	Knob, Rectangle	1
Front Wheel Ass'y	3.2	For Reference Only	For Reference Only	Lever, Height Adjust	1
Front Wheel Ass'y	4	KB21Y.01-04	454000160100	Plastic Washer	1
Front Wheel Ass'y	5	KB21Y-B.01-05	454009860180	Spacer, Height Adjust	1
Front Wheel Ass'y	6	GB/T5789	B01310801666	Bolt, M8X16	1
Front Wheel Ass'y	7	KB21Y-B.01-03	454009961350	Plate, Height Adjust	1
Front Wheel Ass'y	8	GB/T6187.1	B04410800066	Nut, M8	2
Front Wheel Ass'y	9	KB21Y.01.03	454000014901	Lateral Adj. Knob Assembly	1
Front Wheel Ass'y	9.1	For Reference Only	For Reference Only	Knob, Molded	1
Front Wheel Ass'y	9.2	KB21Y-B.01-10	454000060203	Spring	1
Front Wheel Ass'y	10	KB21Y-B.01-01	454002250702	Shaft, Curb Hopping	1
Front Wheel Ass'y	11	KB21Y.01-02	454000160000	Push Nut, Washer	1
Front Wheel Ass'y	12	KB31Y.02.01	454020011300	Tire & Rim	2
Front Wheel Ass'y	13	GB/T5783	B01270811086	Bolt, M8X110	1
Front Wheel Ass'y	14	KB21Y.02-02	454000160302	Flatwasher	2
Front Wheel Ass'y	15	KB21Y.02-01	454000280002	Spacer, Sleeve	2
Front Wheel Ass'y	16	KB21Y.01.01	454000011101	Front Wheel Arm Assembly.	1
Front Wheel Ass'y	16.1	For Reference Only	For Reference Only	Front Wheel Arm	1
Front Wheel Ass'y	16.2	KB21Y.01.01-02	454009880100	Insert, ST8X1.25	1



QUILL ARM ASSY


Quill Arm Ass'y	1	KB51Y.05-03	468030080200	Lock Nut, M10	1
Quill Arm Ass'y	2	KB21Y.05-11	454000160802	Flatwasher	1
Quill Arm Ass'y	3	KB21Y.05-10	454000160702	Flatwasher	1
Quill Arm Ass'y	4	KB51Y.05.02	468000014800	Quill Support Assembly	1
Quill Arm Ass'y	4.1	KB51Y.05.02.01	468030011200	Quill Support	1
Quill Arm Ass'y	4.2	GB/T5789	B01310501266	Bolt, M5X12	5
Quill Arm Ass'y	4.3	KB21Y-B.05.06	454000014950	Blade Angle Control Bracket	1
Quill Arm Ass'y	4.4	KB21Y-B.09-07	454009952200	Label, Blade Angle	1
Quill Arm Ass'y	4.5	KB21Y.05-12	454009970080	Rubber Deflector	1
Quill Arm Ass'y	5	KB51Y.05-02	468030080100	Bolt	1





BLADE ARM ASSY

Blade Arm Ass'y	1	KB21Y.05.04	454000013701	Index Lever	1
Blade Arm Ass'y	2	KB21Y.02-02	454000160302	Flatwasher	1
Blade Arm Ass'y	3	KB21Y.05-08	454000170006	Spring, Torsion	1
Blade Arm Ass'y	4	KB51Y.05.01	468030010900	Drive Shaft Assembly	1
Blade Arm Ass'y	4.1	KB51Y.05.01.01	468030011100	Blade Arm	1
Blade Arm Ass'y	4.2	GB/T276	B*2602031300	Bearing, 6203-2RS	2
Blade Arm Ass'y	4.3	GB/T6176	454009881205	Nut, M12X1.25	1
Blade Arm Ass'y	4.4	KB21Y.01-09	454000160206	Flatwasher	1
Blade Arm Ass'y	4.5	KB21Y.05.01-02	454000160602	Flatwasher	3
Blade Arm Ass'y	4.6	KB21Y.05.01-04	454000090000	Key	1
Blade Arm Ass'y	4.7	KB21Y.05.01-01	454002230000	Drive Shaft	1
Blade Arm Ass'y	4.8	KB21Y.05.01-03	454001280003	Pulley, Half "V"	2
Blade Arm Ass'y	4.9	KB21Y.05-13	454009881102	Nut, M12X1.25	1
Blade Arm Ass'y	4.10	KB51Y.05.01-01	468030160100	Washer	1
Blade Arm Ass'y	5	GB/T6182	B04340800066	Nut, M8	1
Blade Arm Ass'y	6	KB21Y.05-06	454000060002	Spring	1
Blade Arm Ass'y	7	GB/T6187.1	B04410800066	Nut, M8	3
Blade Arm Ass'y	8	GB/T6182	B04340600066	Nut, M6	1
Blade Arm Ass'y	9	KB31Y.05.03	454020012540	Guide, Belt	1
Blade Arm Ass'y	10	GB/T5789	B01310602566	Bolt, M6X25	1
Blade Arm Ass'y	11	GB/T5789	B01310501266	Bolt, M5X12	2
Blade Arm Ass'y	12	KB21Y.05-05	454009960450	Cover, Quill Pulley	1
Blade Arm Ass'y	13	KB21Y.01-09	454000160206	Flatwasher	1
Blade Arm Ass'y	14	KB21Y.05-14	454009881302	Nut, M12X1.25	1
Blade Arm Ass'y	15	KB21Y.05-01	454002080008	Blade, Edger	1
Blade Arm Ass'y	16	KB21Y.05-03	454009880202	Bolt, Carriage	3
Blade Arm Ass'y	17	KB21Y-B.05.07	454000015101	Blade Guard, Assembly	1
Blade Arm Ass'y	17.1	KB21Y-B.09-08	454009952300	Label, Blade Danger	1
Blade Arm Ass'y	17.2	For Reference Only	For Reference Only	Blade Guard	1
Blade Arm Ass'y	18	KB51Y.05-01	468031270100	Belt	1




HANDLE ASSY					
Handle Ass'y	1	KB51Y.06.01	468000014100	Upper Handle Assembly	1
Handle Ass'y	1.1	KB21Y.06.01-02	454001220080	Tubing, Foam	1
Handle Ass'y	1.2	KB51Y.06.01-01	468031170124	Upper Handle	1
Handle Ass'y	1.3	KB21Y-B.09-11	454009952500	Label, Start/Stop	1
Handle Ass'y	1.4	KB21Y-B.09-15	454009952700	Label, Wire Warning	1
Handle Ass'y	1.5	KB21Y-B.09-03	454009951800	Label, Cutting Depth	1
Handle Ass'y	2	KB21Y-B.06.03	454001970100	Flameout Wire	1
Handle Ass'y	3	KB21Y.06.01.01	454000013650	Start Lever	1
Handle Ass'y	4	KB21Y.06-13	454000170007	Torsion Spring	1
Handle Ass'y	5	KB21Y.06-12	454009961602	Flatwasher	1
Handle Ass'y	6	GB/T6182	B04340500066	Nut, M5	1
Handle Ass'y	7	QJ1E38QCA-5.9.3-17	384313A13F000	Cable Tie	3
Handle Ass'y	8	XB51Y.02-09	464042340005	Guide, Rope	1
Handle Ass'y	9	XSSL46A-03-29	210020081400	Nut, 1/4-20	1
Handle Ass'y	10	KB21Y.06-07	454009880905	Bolt	2
Handle Ass'y	11	KB21Y-B.06-06	454001170408	Lower Handle	1
Handle Ass'y	12	GB/T5789	B01310801666	Bolt, M8X16	4
Handle Ass'y	13	GB/T6187.1	B04410800066	Nut, M8	6
Handle Ass'y	14	KB21Y-B.03.01-01	454001180281	Knob, Wing	2
Handle Ass'y	15	GB/T6182	B04340800066	Nut, M8	3
Handle Ass'y	16	KB21Y-B.06.05	454000015000	Nameplate Assembly	1
Handle Ass'y	16.1	KB21Y-B.09-13	454009951500	Label, Warning	1
Handle Ass'y	16.2	For Reference Only	For Reference Only	Nameplate	1
Handle Ass'y	17	XSSL48A-02.03-02	C5300002K1F001	Hair Pin	2
Handle Ass'y	18	KB21Y.06-08	454002250408	Control Rod	1
Handle Ass'y	19	GB/T5783	B01270603266	Bolt, M6X32	2
Handle Ass'y	20	GB/T5783	B01270803066	Bolt, M8X30	1
Handle Ass'y	21	GB/T6187.1	B04411000066	Nut, M10	1
Handle Ass'y	22	KB51Y.06-01	468032370108	Depth Selector Plate	1
Handle Ass'y	23	KB21Y.06-03	454009880602	Stud	1
Handle Ass'y	24	KB21Y-B.06-02	454001170508	Depth Adjust Lever	1
Handle Ass'y	25	KB21Y.06-01	454009980250	Grip, Depth Lever	1

HANDLE ASSY					
Handle Ass'y	26	KB21Y.06-05	454000060102	Spring, Compression	1
Handle Ass'y	27	KB21Y-B.06-07	454009881405	Bolt	2
Handle Ass'y	28	GB/T845	B05003501266	Screw, ST3.5X12.7	1
Handle Ass'y	29	KB21Y.06-15	454009961500	Clip, Grounding	1
Handle Ass'y	30	KB21Y.06-14	454009980380	Insulator, Operator Control	1
Handle Ass'y	31	GB/T6182	B04340600066	Nut, M6	2
Handle Ass'y	32	KB21Y-B.06.06	454000015200	Grounding Terminal	1


ENGINE SUB ASSY

Engine Sub-Level Ass'y	1	For Reference Only	For Reference Only	Air Filter Assembly	1
Engine Sub-Level Ass'y	2	For Reference Only	For Reference Only	Carburator Assembly	1
Engine Sub-Level Ass'y	3	For Reference Only	For Reference Only	Cylinder Head Assembly	1
Engine Sub-Level Ass'y	4	For Reference Only	For Reference Only	Fuel Tank Assembly	1
Engine Sub-Level Ass'y	5	For Reference Only	For Reference Only	Muffler Assembly	1
Engine Sub-Level Ass'y	6	For Reference Only	For Reference Only	Centrifugal Governor Assembly	1
Engine Sub-Level Ass'y	7	For Reference Only	For Reference Only	Piston & Connecting Rod Assembly	1
Engine Sub-Level Ass'y	8	For Reference Only	For Reference Only	Crankcase Cover Assembly	1
Engine Sub-Level Ass'y	9	For Reference Only	For Reference Only	Crankcase Assembly	1
Engine Sub-Level Ass'y	10	QJ182QDP.04-03	15116Q01F000	Key	1
Engine Sub-Level Ass'y	11	For Reference Only	For Reference Only	Crankcase Assembly	1
Engine Sub-Level Ass'y	12	For Reference Only	For Reference Only	Fly Wheel Assembly	1
Engine Sub-Level Ass'y	13	For Reference Only	For Reference Only	Engine Side Assembly	1
Engine Sub-Level Ass'y	14	ZJ168FJH.11.01	168031970100	Grounded Fire Assembly	1
Engine Sub-Level Ass'y	15	QJ168QDJ.11.03	34350K07F000	Ignition Coil	1
Engine Sub-Level Ass'y	16	GB5789-86	B01090602563	Bolt	2
Engine Sub-Level Ass'y	17	For Reference Only	For Reference Only	Valve Timing Assembly	1



CRANKCASE COVER ASSY

Crankcase Cover Ass'y	1	GB5787-86	B01070803264	Bolt	6
Crankcase Cover Ass'y	2	QJ168QDJ.01.01	26133K07F000	Oil Seal	1
Crankcase Cover Ass'y	3	QJ168QDJ.01-04	168032240100	Dipstick	1
Crankcase Cover Ass'y	4	JF142F.8-5	35100005B31F000	Oil Seal, Dipstick	1
Crankcase Cover Ass'y	5	QJ168QDJ.01-01	14132K07F000	Cover, Crankcase	1
Crankcase Cover Ass'y	6	GB/T276-94	B12016620553	Bearing	1
Crankcase Cover Ass'y	7	QJ168QDJ-01-02	26201K07F000	Gasket, Crankcase	1



CRANKSHAFT ASSY

Crankshaft Ass'y


2

ZJ168FJH.04-08

168030400100


Crankshaft

1




PISTON & CONNECTING ROD ASSY

Piston & Connecting Rod Ass'y	1	QJ168QDJ.04.01A	16801K07F100	Piston Ring Assembly	1
Piston & Connecting Rod Ass'y	1.1	For Reference Only	For Reference Only	Ring, First	1
Piston & Connecting Rod Ass'y	1.2	For Reference Only	For Reference Only	Ring, Second	1
Piston & Connecting Rod Ass'y	1.3	For Reference Only	For Reference Only	Oil Ring	1
Piston & Connecting Rod Ass'y	2	QJ168QDJ.04-05	15106K07F000	Circlip, Piston Pin	2
Piston & Connecting Rod Ass'y	3	QJ168QDJ.04-04	15105K07F000	Pin, Piston	1
Piston & Connecting Rod Ass'y	4	QJ168QDJ.04-01	15100K07F000	Piston	1
Piston & Connecting Rod Ass'y	5	QJ168QDJ.04.02	15130K07F000	Connecting Rod Assembly	1
Piston & Connecting Rod Ass'y	5.1	For Reference Only	For Reference Only	Connecting Rod Body	1
Piston & Connecting Rod Ass'y	5.2	For Reference Only	For Reference Only	Connecting Rod Cover	1
Piston & Connecting Rod Ass'y	5.3	For Reference Only	For Reference Only	Connecting Rod Bolt	2




MUFFLER ASSY

Muffler Ass'y	1	GB/T818-2000	B02210501040	Bolt	5
Muffler Ass'y	2	GB/T93	B07000005000	Spring Washer	5
Muffler Ass'y	3	GB/T95	B07010005000	Washer	5
Muffler Ass'y	4	ZJ168FJH.08.02A	168030940300	Muffler Cover Assembly	1
Muffler Ass'y	4.1	For Reference Only	For Reference Only	Muffler Cover	1
Muffler Ass'y	4.2	ZJ151FEH.10-08	151009950100	Label, Hot Surface	1
Muffler Ass'y	5	ZJ168FJH.08.02	168030940200	Muffler	1
Muffler Ass'y	6	ZJ168FJH.08-01	168039960200	Redirector	1
Muffler Ass'y	7	GB/T818-2000	B02210400640	Bolt	2
Muffler Ass'y	8	GB/T95	B07010004000	Washer	2




AIR FILTER ASSY

Air Filter Ass'y	1	GB62-88	B34030600040	Wingnut	2
Air Filter Ass'y	2	GB/T95	B37010006000	Washer	1
Air Filter Ass'y	3	QJ168QDJ.07.03A	37113K07F100	Air Filter Cover Assembly	1
Air Filter Ass'y	3.1	For Reference Only	For Reference Only	Air Filter Cover	1
Air Filter Ass'y	3.2	ZJ1P64FJV.15-19	164049952500	Label, Air Cleaner Maintenance	1
Air Filter Ass'y	4	ZJ168FJH.07.01.01-02	168030100100	Seal Spacer	1
Air Filter Ass'y	5	ZJ168FJH.07.01.01	168030010900	Air Cleaner Element	1
Air Filter Ass'y	6	ZJ168FJH.07.01-02	168032270300	Air Cleaner Housing	1
Air Filter Ass'y	7	ZJ168FJH.07-02	168030100200	Seal Spacer	1
Air Filter Ass'y	8	QJ168QDJ.07.01	37300 K07F000	Air Cleaner Body	1
Air Filter Ass'y	9	QJ168QDJ.07-02	26400K07F001	Breather Tube	1
Air Filter Ass'y	10	QJ168QDJ.07.03	37113K07F000	Spacer	1




CARBURETOR ASSY

Carburetor Ass'y	1	ZJ168FJH.09.01	668030570100	Carburetor	1
Carburetor Ass'y	2	ZJ168FJH.09-01	168030320100	Hose, Fuel	1
Carburetor Ass'y	3	PD24J-08-04	32002J02F000	Clamp, Fuel Line, ø 6.5	2
Carburetor Ass'y	4	QJ162FL.05.01.07	164040013800	Primer Bulb	1




CENTRIFUGAL GOVERNOR ASSY

Centrifugal Governor Ass'y	1	QJ168QDJ.05-01	17581K07F000	Arm	1
Centrifugal Governor Ass'y	2	QJ168QDJ.05-07	17594K07F000	Rod, Tension	1
Centrifugal Governor Ass'y	3	QJ168QDJ.05-06	17593K07F000	Spring 2, Tension	1
Centrifugal Governor Ass'y	4	GB6177	B04070610064	Nut	1
Centrifugal Governor Ass'y	5	QJ182QDJ.06-03	17589Q01F920	Bolt, Square	1
Centrifugal Governor Ass'y	6	QJ168QDJ.05-09	17585K07F000	Spacer 2	1
Centrifugal Governor Ass'y	7	QJ182QDP.06-02	17590Q01F000	Hair Pin	1
Centrifugal Governor Ass'y	8	QJ168QDJ.05-03	17582K07F000	Governor Crank	1
Centrifugal Governor Ass'y	9	QJ166QDK.06-03	17584L01F000	Spacer 1	1
Centrifugal Governor Ass'y	10	QJ168QDJ.05-04	17627K07F000	Pin	1
Centrifugal Governor Ass'y	11	QJ166QDK.01-02	26146L01F000	Circlip	1
Centrifugal Governor Ass'y	12	QJ168QDJ.05.02-01	17587K07F000	Body, Centrifugal Governer	1
Centrifugal Governor Ass'y	13	QJ168QDJ.05.02-03	17588K07F000	Pawl	2
Centrifugal Governor Ass'y	14	QJ168QDJ.05.02-02	17591K07F000	Pin	2
Centrifugal Governor Ass'y	15	QJ168QDJ.05-08	17586K07F000	Spacer 3	1
Centrifugal Governor Ass'y	16	QJ168QDJ.05-02	17583K07F000	Cover, Push Rod	1
Centrifugal Governor Ass'y	17	QJ168QDJ-2.02-01	17592K11F000	Spring 1, Tension	1
Centrifugal Governor Ass'y	18	GB5789-86	B01090601064	Bolt	1
Centrifugal Governor Ass'y	19	QJ168QDJ-2.02.01	17550K11F000	RPM Adj Mechanism	1
Centrifugal Governor Ass'y	20	GB5789-86	B01090602064	Bolt	2




FLY WHEEL ASSY

Fly Wheel Ass'y	1	QJ168QDJ.04-06	15230K07F000	Nut, Clamp	1
Fly Wheel Ass'y	2	QJ168QDJ.04-10	17403K07F000	Start-Up Ratchet Gear	1
Fly Wheel Ass'y	3	QJ168QDJ.04-11	34381K07F000	Fan Wheel	1
Fly Wheel Ass'y	4	QJ168QDJ.04.03	34309K07F000	Flying Wheel	1




FUEL TANK ASSY

Fuel Tank Ass'y	1	QJ168QDJ.10.02	32133K07F000	Fuel Tank Cap	1
Fuel Tank Ass'y	2	QJ168QDJ.10.02.01	32138K07F000	Filter Net	1
Fuel Tank Ass'y	3	ZJ168FJH.10.04	168030990100	Fuel Tank	1
Fuel Tank Ass'y	4	GB6177	B04070610064	Nut	2
Fuel Tank Ass'y	5	QJ168QDJ.10.01	32145K07F000	Fuel Line Fitting / Filter	1
Fuel Tank Ass'y	6	P23-08-15	32134H03F000	Circlip	2
Fuel Tank Ass'y	7	QJ168QDJ.10.03-01	32135K07F000	Fuel Line	1
Fuel Tank Ass'y	8	QJ168QDJ.10.03-02	32238K07F000	Sleeve, Protecting	1
Fuel Tank Ass'y	9	WJF1E40MB.09-02	36002B00Y000	Washer, Shock Absorbing	2




ENGINE SIDE ASSY

Engine Side Ass'y	1	ZJ168FJH.06	168030010400	Starter Assembly	1
Engine Side Ass'y	1.1	QJ168QDJ.06-05	17180K07F000	Screw	1
Engine Side Ass'y	1.2	QJ168QDJ.06-06	17156K07F000	Circlip	1
Engine Side Ass'y	1.3	QJ168QDJ.06-04	17157K07F000	Guide Pan	1
Engine Side Ass'y	1.4	QJ168QDJ.06-01	17158K07F000	Ratchet	2
Engine Side Ass'y	1.5	QJ168QDJ.06-02	17162K07F000	Compression Spring	2
Engine Side Ass'y	1.6	QJ168QDJ.06-03	17155K07F000	Spool	1
Engine Side Ass'y	1.7	QJ168QDJ.06-07	17152K07F000	Wind Spring	1
Engine Side Ass'y	1.8	GB5789-86	B01090608064	Bolt	3
Engine Side Ass'y	1.9	JF168FLH-15.03.01	17170K07F000	Starter Cover	1
Engine Side Ass'y	1.10	ZJ168FJH.06.01-01	168031210100	Starter Rope	1
Engine Side Ass'y	1.11	QJ1P64.11-1	181051C03000	Handle, Recoil Starter	1
Engine Side Ass'y	2	ZJ168FJH.06.02	168030011100	Engine Side Cover Assembly	1
Engine Side Ass'y	2.1	For Reference Only	For Reference Only	Engine Side Cover	1
Engine Side Ass'y	2.2	ZJ168FJH.12-01	168039950100	Label, Primer	1
Engine Side Ass'y	2.3	JF168FJH.12-02	168019951200	Label, EPA	1
Engine Side Ass'y	3	GB5789-86	B01090601064	Bolt	6
Engine Side Ass'y	4	QJ168QDJ.06.02.01	17178K07F002	Shield 1	1
Engine Side Ass'y	5	GB5789-86	B01090601464	Bolt	1
Engine Side Ass'y	6	QJ168QDJ.06.02-01	17178K07F001	Shield 2	1
Engine Side Ass'y	7	QJ168QDJ.06.02.01.03	17188K07F000	Plug	1




CYLINDER HEAD ASSY

Cylinder Head Ass'y	1	QJ168QDJ.02.02	30707K07F000	Gasket, Cylinder Head	1
Cylinder Head Ass'y	2	GB5787-86	B01070806064	Bolt, Cylinder Head	4
Cylinder Head Ass'y	3	QJ168QDJ.02.01-05	30110K07F000	Ring, Intake Valve	1
Cylinder Head Ass'y	4	QJ168QDJ.02.01-06	30109K07F000	Canal, Intake Valve	1
Cylinder Head Ass'y	5	QJ168QDJ.02.01-02	30206K07F000	Ring, Exhaust Valve	1
Cylinder Head Ass'y	6	QJ168QDJ.02.01-03	30207K07F000	Canal, Exhaust Valve	1
Cylinder Head Ass'y	7	QJ168QDJ.02.01-04	30216K07F000	Washer, Stop	1
Cylinder Head Ass'y	8	GB6177	B04070610064	Nut	2
Cylinder Head Ass'y	9	QJ168QDJ.02-03	30520K07F000	Double End Stud	2
Cylinder Head Ass'y	10	QJ168QDJ.02-05	30715K07F000	Gasket, Intake 1	1
Cylinder Head Ass'y	11	QJ168QDJ.02-02	30516K07F000	Spacer, Heat Insulating	1
Cylinder Head Ass'y	12	QJ168QDJ.02-04	30715K07F001	Gasket, Intake 2	1
Cylinder Head Ass'y	13	QJ168QDJ.02.01-01	30501K07F000	Cylinder Head	1
Cylinder Head Ass'y	14	QJ168QDJ.02-06	30702K07F000	Gasket, Cylinder Head Cover	1
Cylinder Head Ass'y	15	QJ168QDJ.02.03	30700K07F000	Cylinder Head Cover	1
Cylinder Head Ass'y	16	GB5789-86	B01090601464	Bolt	4
Cylinder Head Ass'y	17	QJ1E50FMG.1.2	30506G15F910	Spark Plug	1
Cylinder Head Ass'y	18	GB6170	B04000812564	Nut	2
Cylinder Head Ass'y	19	QJ168QDJ.02-07	30521K07F000	Double End Stud	2
Cylinder Head Ass'y	20	QJ168QDJ.02-01	36101K07F000	Gasket, Exhaust	1



VALVE TIMING ASSY

Valve Timing Ass'y	1	QJ166QDK.03-11	30302L01F000	Nut, Valve Clearance Adjustment	2
Valve Timing Ass'y	2	QJ182QDP.03-07	30313Q01F000	Buttonhead, Arm	2
Valve Timing Ass'y	3	QJ168QDJ.03-09	30301K07F000	Arm	2
Valve Timing Ass'y	4	QJ168QDJ.03-02	30214K07F000	Cap, Exhaust Rod	1
Valve Timing Ass'y	5	QJ168QDJ.03-10	30203K07F000	Upper Retainer, Exhaust Valve Spring	1
Valve Timing Ass'y	6	QJ168QDJ.03-07	30101K07F930	Spring, Valve	2
Valve Timing Ass'y	7	QJ168QDJ.03-05	30201K07F000	Valve, Exhaust	1
Valve Timing Ass'y	8	QJ168QDJ.03.04	30240K07F000	Guide Plate, Connecting Stud	1
Valve Timing Ass'y	9	QJ168QDJ.03.02	30230K07F000	Rod, Connecting	2
Valve Timing Ass'y	10	QJ168QDJ.03-08	30106K07F000	Upper Retainer, Intake Valve Spring	1
Valve Timing Ass'y	11	QJ182QDP.03-04	30303Q01F930	Adjusting Stud, Valve Clearance	2
Valve Timing Ass'y	12	QJ168QDJ.03-06	30103K07F000	Valve, Intake	1
Valve Timing Ass'y	13	QJ168QDJ.03-01	30312K07F000	Stud, Connecting	2
Valve Timing Ass'y	14	QJ168QDJ.03.01	30400K07F000	Camshaft	1
Valve Timing Ass'y	15	QJ1P64.02.01	30104K07F000	Oil Seal, Valve	1



CRANKCASE ASSY

Crankcase Ass'y	1	QJ168QDJ.01.02	26001K07F000	Crankcase Body	1
Crankcase Ass'y	2	157.3- 8	26218J01F000	Guide Dowel	2
Crankcase Ass'y	3	GB/T276 - 94	B12016620553	Bearing	1
Crankcase Ass'y	4	QJ166QDK.01-06	26202L01F000	Drain Plug	2
Crankcase Ass'y	5	QJ166QDK.01-07	26204L01F000	Washer, Drain Plug	2
Crankcase Ass'y	6	QJ168QDJ.01.01	26133K07F000	Oil Seal	1
Crankcase Ass'y	7	157.4-6	26208J01F000	Guide Dowel	2
Crankcase Ass'y	8	GB5789-86	B01090602564	Bolt	1

